


Wi-Fi Upgrade Instructions

SolaX Power




1. With any wireless enabled device such as a laptop, tablet, smartphone etc, navigate to the device settings > Wi-Fi. Here you will see a list of SSID's that are visible, find the SSID **Solax_******* as shown in the screenshot and connect to it.


Please note, the network may show 'unsecured network' on some devices, this is normal.

2. Once connected to the **Solax_******* network, open up any web browser on the device you are using. Some browsers will display a 'no internet connection' message, this is normal.

In the address bar at the top of the page. **NOT A GOOGLE SEARCH**, input the following IP address: **5.8.8.8** and press enter on the keyboard




3. A box will appear asking you to enter a username and password. The details for this are **admin, admin**. Both in lowercase,



4. Once signed in, this is the screen you will see. We need to click on the '**System**' tab.

A new window will appear and you will see a button that says 'Choose file'. Please click on this and select the 'PocketWifiv2.33.7.usb' file you saved onto your desktop.



Now click on 'Start' and wait for it to upload the file. Once done, it will bring you onto a new page that says 'Firmware setting success'.